



6420 Leaf Wetness Sensor, Vantage Pro® and Vantage Pro2™

Use to monitor the level of surface moisture on foliage, with range from 0 (completely dry) to 15 (saturated). Add up to 2 sensors to a single Wireless Leaf & Soil Moisture/Temperature Station. Includes 40' (12 m) cable.

The Leaf Wetness Sensor must be connected via a Leaf & Soil Moisture/Temperature Station (#6345AU).