

6152AU Wireless Vantage Pro2™ with Standard Radiation Shield



A wireless weather station with a versatile sensor suite that combines our rain collector, temperature and humidity sensors and anemometer into one package. You can customize your Vantage Pro2 by adding consoles or the special-purpose options. Available in both wireless and cabled versions.

First and only weather station in its class to use frequency hopping spread spectrum radio technology to transmit weather data wirelessly up to 1,000 ft (300 m).

Features

- Large, backlit 3.5" x 6" (9 x 15 cm) LCD screen
- Options available for UV/solar, soil moisture, short and long-range repeaters, and much more
- Fast updates every 2.5 seconds
- Optional WeatherLink data logger and software offer additional analyses in a variety of versions
- Wireless transmission from station to console up to 1,000 ft. (300 m)

Includes

- Solar powered Integrated Sensor Suite:
 - Rain collector
 - Temperature and humidity sensors
 - Anemometer with 40' (12 m) anemometer cable
 - Solar panel

- Vantage Pro2 console/receiver
- Power adapter for console
- Mounting hardware

Don't forget to add a #07717 Mounting Pole or #07716 Mounting Tripod with your station purchase.

Specifications

- Electronic components are housed in a weather-resistant shelter.
- Console may be powered using the included power adapter or with three C batteries (not included).
- Wireless range is up to 1,000 ft (300 m) outdoors, line of sight. Typical range through walls under most conditions is 200 to 400 ft (60 to 120 m).
- Add wireless repeaters for distances up to 1.7 miles (2.7 km).