



6382AU Wireless Temperature/Humidity Station

Customize your Vantage Pro2 weather station, Weather Envoy or Envoy8X by adding special-purpose stations and sensors.

This battery-powered wireless station will transmit Temperature and Humidity readings to a Vantage Pro2 console/receiver, a Weather Envoy, or Envoy8X. The data can be viewed using the Vantage Pro2 console or by using either a Weather Envoy or Envoy8X with WeatherLink.

Features

- Temperature and humidity sensors are inside a protective radiation shield that protects against solar radiation and other sources of radiated and reflected heat
- Wireless transmitter and battery are inside a weather-resistant shelter
- Updates every 2.5 seconds
- Frequency-hopping spread spectrum radio for continuous data transmission

Includes

- Temperature and humidity sensors
- Radiation shield
- Transmitter
- Lithium battery
- Hardware for mounting on fence post or pole

Specifications

- Wireless transmission up to 1,000 ft. (300 m)
- Expected battery life for included lithium battery is 6-9 months under normal conditions
- Not compatible with original Vantage Pro or as an additional station for Vantage Vue