



6490 UV Sensor

Measures the sunburning portion of the UV spectrum. Allows you to display UV index, dose rate, and daily and accumulated dose.

Multi-layer filter provides a spectral response that closely matches the Erythema Action Spectrum. Diffuser provides excellent cosine response. Two-piece housing minimizes radiation heating, allows convection cooling of the sensor, and prevents the trapping of water or dust. Includes built-in level and 2' (0.6 m) cable.

Compatible with both original Vantage Pro and Vantage Pro2. (Already included with Vantage Pro Plus and Vantage Pro2 Plus.)

You may also need a Solar Sensor (#6450) and Sensor Mounting Shelf (#6673).