



**XChange 2**  
Your Detecting Connection

Easily manage your detecting and location data. XChange 2 is supplied on the CTX 3030 CD, or is available as a FREE download from: [www.minelab.com/apps](http://www.minelab.com/apps)

## Identify... Detect... Map... Store...

Discover more historical treasures with the most accurate target identification available. With Minelab's exclusive integrated GPS, you can navigate to your favorite locations and record your finds. With a range of identify... Detect... Map... Store... functions, the CTX 3030 does it all.

### Detect Screen



#### Identify

Adjusts the detector to accept good targets and reject trash.



#### Detect

Displays the Detect Screen, showing target data, and selects from two discrimination patterns.



### Map Screen



#### Map

Displays the Map Screen, showing GPS data, and selects from three zoom levels.



#### Store

Records GPS data for WayPoints, FindPoints, and GeoHunts.



## Accessories



CTX 06  
Smart Coil  
(part # 3011-0114)



CTX 17  
Smart Coil  
(part # 3011-0116)



Waterproof  
Headphones  
(part # 3011-0134)



WM 10  
Wireless Module\*\*  
(part # 3011-0120)



Replaceable  
Battery Pack^^  
(part # 3011-0117)

	Starter Pack (part # 3228-0102)	Standard Pack (part # 3228-0101)
<b>Overview</b>	Ultimate performance multi-frequency TREASURE detector with enhanced FeCo discrimination, integrated GPS and wireless audio options all in a sleek rugged design that is waterproof to 10 ft (3 m)	
<b>Search Modes</b>	10 fully customizable, including 5 preset (Coins, Beach, Relic, Silver & High Trash) 2 Pinpoint options (Normal and Sizing)	
<b>Discrimination Patterns</b>	20 fully customizable (2 per Search Mode)	
<b>Discrimination Type</b>	Enhanced Color discrimination (35 Fe x 50 Co = 1750 segments), Target Trace, Target Trace Pinpoint, Tone ID Profiles, Target Separation (Ferrous-Coin and Ground-Coin), Accept / Reject cursors	
<b>Standard Coil</b>	11-inch waterproof Double-D smart coil	
<b>Audio Outputs</b>	Built-in speaker, standard 1/4-inch non waterproof socket, custom waterproof socket (Minelab accessory headphones only)	
<b>Wireless Audio (WM 10)</b>	No (available as accessory)	Yes (supplied with detector)
<b>Headphones</b>	KOSS UR30 (100 ohm) supplied with detector (non-waterproof)	
<b>Batteries (Li-ion pack)</b>	Yes (with mains charger). 12 V car adapter supplied with Standard Pack only	
<b>Batteries (8 x AA pack)</b>	No (available as accessory)	Yes (supplied with detector^)
<b>Key Technologies</b>	FBS 2, Smartfind 2, GPSi, Wi-Stream	

\*Standard headphones, removable headphone module and WM 10 module are not waterproof. ^WM 10 supplied with Standard Pack only. Available as accessory for Starter Pack. \*\*Supplied with Standard Pack only. Available as accessory for Starter Pack. ^^Not supplied with AA battery cells.

**MINELAB**  
www.minelab.com

**CTX 3030**

*The Future of Discovery*

CTX 3030 OVERVIEW



**Minelab Electronics Pty. Ltd.**  
(Oceania & Asia)  
118 Hayward Ave, Torrensville  
Adelaide, South Australia 5031  
**Australia**  
Tel: +61 (0) 8 8238 0888  
Fax: +61 (0) 8 8238 0890  
Email: [minelab@minelab.com.au](mailto:minelab@minelab.com.au)

**Minelab International Ltd.**  
(Europe, Middle East & Africa)  
Unit 207, Harbour Point Business Park  
Little Island, Co. Cork  
**Ireland**  
Tel: +353 (0) 21 423 2352  
Fax: +353 (0) 21 423 2353  
Email: [minelab@minelab.ie](mailto:minelab@minelab.ie)

**Minelab Americas Inc.**  
(North & South America)  
2777 Finley Road. Unit #4.  
Downers Grove, IL. 60515  
**USA**  
Tel: +1 888 949 6522  
Fax: +1 630 401 8180  
Email: [info@minelabamericas.com](mailto:info@minelabamericas.com)

Minelab®, CTX®, Smartfind™ 2, FBS™ 2, Wi-Stream™, GPSi™, FindPoint®, GeoHunt™, GeoTrail™, XChange Your Detecting Connection™, Target Trace™, Ferrous-Coin Separation™, Ground-Coin Separation™ are trademarks of Minelab Electronics Pty. Ltd. Google Maps is a trademark of Google Inc. u-blox is a trademark of u-blox Holding AG.



FBS 2 Smartfind 2 GPSi Wi-Stream

**World's Best Metal Detection Technologies**

**MINELAB**  
www.minelab.com

# FIND THE TREASURES

The waterproof all-terrain CTX 3030 is the ultimate TREASURE detector.

# OTHERS HAVE MISSED

Uncover history and record your find locations with integrated GPS.



**Wireless Audio**  
Enjoy detecting freedom without cables attached to your detector. ^

**Ultimate FeCo Discrimination**  
Identify multiple targets, at the same time, for accurate results.

**Full Color Display**  
Displays more target info and enhances discrimination ability.

**GPS**  
**GPS Locating**  
See where you have been and mark your treasure locations.

**PC Mapping (Google Maps)**  
Manage detector settings and treasure locations via XChange 2.

**10FT/3M**  
**Waterproof**  
Go detecting anywhere, on land or underwater to 10 ft (3 m).\*

“With the CTX 3030’s ability to identify and display multiple targets under the coil simultaneously, I’ve been isolating and recovering coins from trashy areas like never before.”

**Field Tester - USA**

“Now we’re talking... that’s impressive!!! With Target Trace you seem to have achieved the impossible! I located a coin under a nail with twice its mass, two targets... unbelievable!”

**Field Tester – UK**



You can choose from nine languages:



Visit [www.minelab.com](http://www.minelab.com) or your local dealer for more information.