



nSolution

OnSolution Pty Ltd.

ABN: 36 093 811 271

OnSolution Pty Ltd

PO Box 1007
Baulkham Hills
NSW 2153
Australia

Ph: +61 2 9614 6417
Fax: +61 2 9614 6891
sales@onsolution.com.au
www.onsolution.com.au



KeepAlert CO₂ Logger

The KeepAlert Logger is designed to measure CO₂ levels as well as temperature and humidity. It can 'wake up', take readings, store them in memory and then go back to sleep. This conserves battery power. It has a memory of 5,200 readings. The KeepAlert Logger measures up to 30% CO₂ level

Uses

- Cold Chain Management
- Agricultural Production
- Transport
- Shipping
- Monitoring of office environments
- HVAC Systems
- Storage and Warehousing
- Agricultural Research
- Horticulture
- Greenhouse and Hydroponic Gardens

Features and Benefits

- Automatic recording of CO₂, Temperature and Humidity
- Easy to download information
- Reusable
- Robust
- No need for External Probes
- Cleanable
- NATA Certifiable
- Replaceable batteries
- Non-dispersive Infrared measurement
- Portable
- Single Unit
- On off switch
- Uses 4 x AA batteries

How is it Used?

1. Turn off the KeepAlert Logger
2. Set up how often you want the CO₂, temperature and humidity recorded with the user-friendly software.
3. Place the KeepAlert Logger into the area where data is to be logged.
4. Turn On
5. When required plug the KeepAlert Logger back into the computer and see exactly what happened, when and for how long.
6. Save your results for later reference.

Specifications

Minimum CO₂	0ppm	Accuracy	0.2% vol
Maximum CO₂	300,000ppm (30%)	Resolution	
Minimum Temperature	-30°C	Accuracy	0.2°C @ 25°C
Maximum Temperature	60°C	Resolution	0.2°C or 0.1°C
Minimum Humidity	0%	Accuracy	+/-3%
Maximum Humidity	100%		
Sample Rate	1 min to 255 min	Size	140mm x 90mm x 33mm
Housing Material	Polycarbonate	Delay Start	Manual On Off switch
Guarantee	1 year	Log Storage	5200 readings

KeepAlert Accessories

Kits


The KeepAlertkit is made up of the easy to use KeepAlertsoftware, the KeepAlertReader cable and a case. The KeepAlertsoftware can be freely copied onto multiple PCs and the reader moved between those PCs.

KeepAlert Software

KeepAlertsoftware allows you to quickly and easily

- Set up the KeepAlertsample rate, start delay, high and low alarms and rollover options
- Download the results from the KeepAlertto the PC
- Display results as a table
- Display the results as a graph. The graph supports panning and zooming to easily identify problems
- Save results for a later recall
- Export results to Microsoft excel, Microsoft Word
- Email results

(Minimum PC requirements: Pentium 200MHz; Windows 98,NT3.5, 2000, XP, 32Mmemory, 5MHDD free, mouse, CD-ROM.)



Onsolution has a range of Temperature, Temperature and Humidity and CO2 loggers, data loggers and food safety education material available. Visit our web site at www.onsolution.com.au for further information.