

# PROFESSIONAL WOOD MASTER KIT



## Product code: PTMMK5.1

A kit for instant and accurate measurement of moisture content in a large range of wood species, relative drywall readings and comparative WME (Wood Moisture Equivalent) readings in wood by-products and other building materials. Featuring the Tramex Professional PTM with its built-in pins, a handheld heavy-duty pin probe and a handheld heavy-duty hammer pin probe, the Professional Wood Master Kit comes in a Tramex protective heavy-duty carrying case with die-cut foam lining.

### CONTENTS

1. PTM2.0 - Professional Pin Moisture Meter.
2. Heavy-duty pin-type wood probe.
3. Heavy-duty hammer pin-type wood probe.

### FEATURES OF PTM

- Built-in calibration for 500+ wood species or standard calibration selection.
- Wide moisture content range: 6 - 46% and digital readout to 0.1% accuracy.
- Adjustable temperature correction.
- Reading "Hold" facility to freeze reading.
- Save up to 100 readings for max, min, average and standard deviation statistics.
- Colour LCD screen with brightness adjustment for low-light operation
- Heavy-duty yet light-weight aluminum construction.
- Built-in calibration checks for confirmed accuracy.
- Battery powered. (supplied)
- Built-in pins and socket for use with a choice of external pin probes. (optional)



### MEASURING RANGE - PTM

Moisture Content	6 to 46%MC
WME (Ref) reference scale for building materials:	0 to 100
Drywall reference scale:	0 to 8.5

### SPECIFICATIONS OF KIT

Size:	16.9" x 13.6" x 5.1" (430mm x 345mm x 130mm)
Weight:	7.2lbs (3.3kg)
Power:	4 x AAA Batteries (included)



PTMMK5.1-US 01/17 REV.1.0